



Sony Ericsson w600i Battery Replacement

Removal of the battery allows access to the SIM card and is required to further disassemble the back housing.

Written By: Beau Blanchard



Step 1 — Battery Cover



- Grip the lower portion of the back of the phone and slide downwards.

Step 2 — Battery



- Lift battery at the rounded notch near the bottom of the phone.

To reassemble your device, follow these instructions in reverse order.